


# Natascha



# Natascha



NATASCHA		Gr 1	Gr 2	Gr 3	Gr 4	Gr 5	Gr 6	Gr 7	Gr 8	Gr 9	Gr 10	Gr 11	Gr 12	Gr 13	Gr 14	Gr 15
<b>1 er</b>	122x98x84	436	447	458	68	484	500	526	547	563	579	600	632	648	674	706
<b>1,5 er</b>	142x98x84	516	527	538	549	566	582	610	632	648	665	687	720	736	764	797
<b>2 er</b>	192x98x84	692	710	729	747	774	802	847	884	911	939	975	1030	1057	1103	1158
<b>2,5 er</b>	212x98x84	733	750	766	783	808	833	875	909	934	959	992	1042	1067	1109	1159
<b>3 er</b>	232x98x84	792	810	828	846	873	900	945	981	1008	1036	1072	1126	1153	1198	1252
<b>1 P (96)</b>	96x98x84	377	386	395	404	417	431	453	471	485	498	516	544	557	580	607
<b>1 M (70)</b>	70x98x84	294	301	308	316	327	337	356	370	381	392	406	428	439	457	479
<b>1,5 P (116)</b>	116x98x84	435	444	453	462	475	489	511	529	543	556	575	602	615	638	665
<b>1,5 M (90)</b>	91x98x84	342	350	358	365	377	389	408	423	435	446	462	485	496	516	539
<b>1,5 M (100)</b>	100x98x84	367	376	385	394	408	422	445	464	477	491	510	537	551	574	602
<b>2 P</b>	166x98x84	587	603	619	635	660	684	725	757	782	806	839	888	912	953	1002
<b>2 M</b>	140x98x84	476	490	505	519	540	562	598	626	648	669	698	741	762	798	841
<b>2,5 P</b>	186x98x84	645	662	678	695	721	746	789	822	848	873	907	958	983	513	1077
<b>2,5 M</b>	160x98x84	535	550	565	579	602	624	662	692	714	737	766	811	834	436	916
<b>3 P</b>	206x98x84	348	713	730	748	774	800	843	878	904	930	965	1017	1043	543	1139
<b>3 M</b>	180x98x84	592	608	623	639	663	687	726	758	782	806	837	885	909	474	996
<b>E Circle</b>	122x122x84	580	590	600	610	625	640	665	684	699	714	734	764	778	402	833
<b>E</b>	98x98x84	410	420	430	440	455	470	496	516	531	546	567	597	612	319	668
<b>OT Lch</b>	114x186x84	679	691	704	716	734	752	782	806	825	843	867	903	921	476	988
<b>HO skośny</b>	62x92x45	174	178	183	187	193	199	210	218	224	231	239	252	258	134	281
<b>HO skośny z blatem/ ENGALED WITH TOP TABLE</b>	62x92x45	261	264	267	270	274	279	286	291	296	300	306	314	319	163	334